

```
1 using MySql.Data.MySqlClient;
2 using PlotterDataGH.Properties;
3 using System.Data;
4 using System.Diagnostics;
5 using System.IO;
6 using System.Reflection;
7 using System.Windows;
8 using System.Windows.Controls;
9 using Newtonsoft.Json;
10 using PlotterDataGH;
11 using System.Threading;
12 using System.Net;
13 using System.Collections.Generic;
14 using Microsoft.Data.Sqlite;
15 using System.Text;
16 using System.Net.NetworkInformation;
17 using System.Windows.Media;
18 using System.Threading.Tasks;
19 using System;
20 using Microsoft.Win32.TaskScheduler;
21 using System.Net.Http;
22
23 namespace WpfApp2
24 {
25     /// <summary>
26     /// Interaction logic for UserControl1.xaml
27     /// </summary>
28     ///
29     public partial class UserControl1 : UserControl
30     {
31         bool cartridgeHidden = true;
32         public int plotterId;
33         public string plotterIp;
34         public string serialnm;
35         AutoResetEvent waiter = new AutoResetEvent(false);
36
37         private static readonly HttpClient client = new HttpClient();
38
39         public MainWindow ParentForm { get; set; }
40
41         public UserControl1()
42         {
43             InitializeComponent();
44             btnScan.IsEnabled = false;
45         }
46
47         private void SetTimer()
48         {
49             //Set a timer between pings
50             System.Windows.Threading.DispatcherTimer dispatcherTimer = new DispatcherTimer()
51             dispatcherTimer.Tick += dispatcherTimer_Tick;
52             dispatcherTimer.Interval = new TimeSpan(0, 10, 0);
53             dispatcherTimer.Start();
54         }
55     }
```

```

56     public void loadData()
57     {
58         //Load cartridge data and put it in a class called      ↗
59         cartridgeControl
60         DataTable dataTable = new DataTable();
61         SqlConnection cnn;
62         SqlCommand cmd = null;
63         cnn = new SqlConnection("Data Source=plotterData.db;");
64         cnn.Open();
65         string query = string.Format("SELECT * FROM `cartridge_reading`  ↗
66         where `parent_id` = {0}", plotterId);
67         cmd = new SqlCommand(query, cnn);
68         SqlDataReader reader = cmd.ExecuteReader();
69         dataTable.Load(reader);
70
71         foreach (DataRow row in dataTable.Rows)
72         {
73             RowDefinition rd = new RowDefinition();
74             rd.Height = GridLength.Auto;
75             plotterControl.RowDefinitions.Add(rd);
76             cartridgeControl cartridgeControls = new cartridgeControl();
77             cartridgeControls.lblCartridgeNaam.Content = row      ↗
78             ["cartridge_model"].ToString();
79             cartridgeControls.lblCatridgeVolume.Content = row    ↗
80             ["volume"].ToString();
81             plotterControl.Children.Add(cartridgeControls);
82             Grid.SetRow(cartridgeControls,      ↗
83             plotterControl.RowDefinitions.Count);
84         }
85         RowDefinition last = new RowDefinition();
86         plotterControl.RowDefinitions.Add(last);
87
88         for (int x = plotterControl.RowDefinitions.Count - 1; x > 0; x--)
89         {
90             plotterControl.RowDefinitions[x].Height = new GridLength(0);
91         }
92
93         SetTimer();
94         SendPing();
95     }
96
97     #region Check status
98     private void dispatcherTimer_Tick(object sender, EventArgs e)
99     {
100         //Send a ping to the plotter and if it responds turn the light  ↗
101         green
102         SendPing();
103     }
104
105     private void SendPing()
106     {
107         Ping pingSender = new Ping();
108
109         // When the PingCompleted event is raised,

```

```
106 // the PingCompletedCallback method is called.
107 pingSender.PingCompleted += new PingCompletedEventHandler
    (PingCompletedCallback);
108
109 // Create a buffer of 32 bytes of data to be transmitted.
110 string data = "aaaaaaaaaaaaaaaaaaaaaaaaaaaaa";
111 byte[] buffer = Encoding.ASCII.GetBytes(data);
112
113 // Wait 12 seconds for a reply.
114 int timeout = 12000;
115
116 // Set options for transmission:
117 // The data can go through 64 gateways or routers
118 // before it is destroyed, and the data packet
119 // cannot be fragmented.
120 PingOptions options = new PingOptions(64, true);
121
122 pingSender.SendAsync(plotterIp, timeout, buffer, options, waiter);
123 }
124
125 private void PingCompletedCallback(object sender,
    PingCompletedEventArgs e)
126 {
127     // If the operation was canceled, display a message to the user.
128     if (e.Cancelled)
129     {
130         ellStatus.Fill = new SolidColorBrush(Colors.Red);
131         btnScan.IsEnabled = false;
132
133         // Let the main thread resume.
134         // UserToken is the AutoResetEvent object that the main thread
135         // is waiting for.
136         ((AutoResetEvent)e.UserState).Set();
137     }
138
139     // If an error occurred, display the exception to the user.
140     if (e.Error != null)
141     {
142         ellStatus.Fill = new SolidColorBrush(Colors.Red);
143         btnScan.IsEnabled = false;
144
145         // Let the main thread resume.
146         ((AutoResetEvent)e.UserState).Set();
147     }
148
149     PingReply reply = e.Reply;
150
151     DisplayReply(reply);
152
153     // Let the main thread resume.
154     ((AutoResetEvent)e.UserState).Set();
155 }
156
157 public void DisplayReply(PingReply reply)
158 {
159     if (reply == null)
```

```
160     {
161         return;
162     }
163
164
165     if (reply.Status == IPStatus.Success)
166     {
167         ellStatus.Fill = new SolidColorBrush(Colors.Green);
168         btnScan.IsEnabled = true;
169     }
170     else
171     {
172         ellStatus.Fill = new SolidColorBrush(Colors.Red);
173         btnScan.IsEnabled = false;
174     }
175 }
176
177 #endregion
178
179 private void btnExpand_Click(object sender, RoutedEventArgs e)
180 {
181     //Expand the control which will show the cartridges
182     if(cartridgeHidden)
183     {
184         for(int x = 0; x <= plotterControl.RowDefinitions.Count - 1; x ++
185             ++
186         {
187             plotterControl.RowDefinitions[x].Height = GridLength.Auto;
188         }
189         cartridgeHidden = false;
190
191         Button button = sender as Button;
192         MahApps.Metro.IconPacks.PackIconFontAwesome fe =
193             button.Content as
194             MahApps.Metro.IconPacks.PackIconFontAwesome;
195         fe.Kind =
196             MahApps.Metro.IconPacks.PackIconFontAwesomeKind.AngleDoubleU
197             pSolid;
198     }
199     else
200     {
201         for(int x = plotterControl.RowDefinitions.Count - 1; x > 0;
202             x--)
203         {
204             plotterControl.RowDefinitions[x].Height = new GridLength
205                 (0);
206         }
207         cartridgeHidden = true;
208
209         Button button = sender as Button;
210         MahApps.Metro.IconPacks.PackIconFontAwesome fe =
211             button.Content as
212             MahApps.Metro.IconPacks.PackIconFontAwesome;
213         fe.Kind =
214             MahApps.Metro.IconPacks.PackIconFontAwesomeKind.AngleDoubled
```

```
        ownSolid;
    }
}

private void Button_Click(object sender, RoutedEventArgs e)
{
    AddPlotter addPlotter = new AddPlotter();
    addPlotter.ParentForm = ParentForm;
    addPlotter.editForm(plotterId);
    addPlotter.editingMode = true;
    addPlotter.Show();
}

#region Scanning

private void Button_Click_1(object sender, RoutedEventArgs e)
{
    //Run a scan of this specific plotter
    RunScan(lblMerk.Uid.ToString(), plotterIp,
        lblNaam.Content.ToString());
    MahApps.Metro.IconPacks.PackIconFontAwesome fe = btnScan.Content
        as MahApps.Metro.IconPacks.PackIconFontAwesome;
    fe.Kind =
        MahApps.Metro.IconPacks.PackIconFontAwesomeKind.SyncSolid;
    btnScan.IsEnabled = false;
}

public void RunScan(string Merk, string IP, string Naam)
{
    var debugField = Path.GetDirectoryName(
        Assembly.GetExecutingAssembly().GetName().CodeBase);
    debugField = debugField.Substring(6);
    var filename = debugField + @"ghWebscraper.exe";

    //Start the Converted python file and pass the paramater
    string arguments = string.Format(@"{0} {1} {2} {3}", Merk, IP,
        Settings.Default.sendData, Naam);

    ellStatus.Fill = new SolidColorBrush(Colors.Orange);

    //Process myProcess = new Process();
    //myProcess.Exited += new EventHandler(myProcess_Exited);
    //myProcess.StartInfo.FileName = filename;
    //myProcess.StartInfo.Arguments = arguments;
    //myProcess.Start();

    doStuff(filename, arguments);
}

async System.Threading.Tasks.Task doStuff(string fileName, string
    args)
{
    ParentForm.DisableWhileScanning();
    await RunProcessAsync(fileName, args);
}
```

```
256
257         //MahApps.Metro.IconPacks.PackIconFontAwesome fe = btnScan.Content ➤
           as MahApps.Metro.IconPacks.PackIconFontAwesome;
258         //fe.Kind = ➤
           MahApps.Metro.IconPacks.PackIconFontAwesomeKind.BinocularsSolid;
259         //btnScan.IsEnabled = true;
260
261         ParentForm.fillerGrid.RowDefinitions.Clear();
262         ParentForm.fillerGrid.Children.Clear();
263         ParentForm.LoadData();
264     }
265
266     public static async Task<int> RunProcessAsync(string fileName, string ➤
           args)
267     {
268         using (var process = new Process
269         {
270             StartInfo =
271             {
272                 FileName = fileName, Arguments = args,
273                 UseShellExecute = false, CreateNoWindow = true,
274                 RedirectStandardOutput = true, RedirectStandardError = true
275             },
276             EnableRaisingEvents = true
277         })
278         {
279             return await RunProcessAsync(process).ConfigureAwait(false);
280         }
281     }
282     private static Task<int> RunProcessAsync(Process process)
283     {
284         var tcs = new TaskCompletionSource<int>();
285
286         process.Exited += (s, ea) => tcs.SetResult(process.ExitCode);
287         process.OutputDataReceived += (s, ea) => Console.WriteLine ➤
           (ea.Data);
288         process.ErrorDataReceived += (s, ea) => Console.WriteLine("ERR: " ➤
           + ea.Data);
289
290         bool started = process.Start();
291         if (!started)
292         {
293             //you may allow for the process to be re-used (started = ➤
           false)
294             //but I'm not sure about the guarantees of the Exited event in ➤
           such a case
295             throw new InvalidOperationException("Could not start process: ➤
           " + process);
296         }
297
298         process.BeginOutputReadLine();
299         process.BeginErrorReadLine();
300
301         return tcs.Task;
302     }
303 }
```

```
304
305     #endregion
306
307     #region Send Data
308     private void btnSend_Click(object sender, RoutedEventArgs e)
309     {
310         //Send data to Goedhart Group
311         Await();
312     }
313
314     async System.Threading.Tasks.Task Await()
315     {
316         var task = SendPlotterAsync();
317         int timeout = 1000;
318         if (await System.Threading.Tasks.Task.WhenAny(task,           ↗
319             System.Threading.Tasks.Task.Delay(timeout)) == task)
320         {
321             // task completed within timeout
322         }
323         else
324         {
325             MessageBox.Show("Verbinding met de Goedhart Servers kon niet   ↗
326                 gemaakt worden");
327         }
328     }
329
330     async System.Threading.Tasks.Task SendPlotterAsync()
331     {
332         var values = new Dictionary<string, string>
333         {
334             { "postType", "Plotter" },
335             { "serial_number", serialnm },
336             { "model_id", lblMerk.Uid.ToString() },
337             { "meters_printed", lblMeterstand.Content.ToString() },
338             { "naam", lblNaam.Content.ToString() },
339             { "IP", plotterIp },
340             { "bedrijfs_Naam", Settings.Default.bedrijfsNaam }
341         };
342
343         var content = new FormUrlEncodedContent(values);
344
345         var response = await client.PostAsync("http://10.0.0.125/",   ↗
346             content);
347
348         var responseString = await response.Content.ReadAsStringAsync();
349
350         DataTable dataTable = new DataTable();
351         SqlConnection cnn;
352         SqlCommand cmd = null;
353         cnn = new SqlConnection("Data Source=plotterData.db;");
354         cnn.Open();
355
356         string query = string.Format("SELECT * FROM `cartridge_reading`   ↗
357             where `parent_id` = {0}", plotterId);
358         cmd = new SqlCommand(query, cnn);
```

```
356     SqliteDataReader reader = cmd.ExecuteReader();
357     dataTable.Load(reader);
358
359     foreach (DataRow row in dataTable.Rows)
360     {
361         SendCartridgeAsync(responseString, row
362             ["cartridge_model"].ToString(), row["volume"].ToString(),
363             row["max_volume"].ToString());
364     }
365
366     async System.Threading.Tasks.Task SendCartridgeAsync(string parent_id,
367         string cartridge_model, string volume, string max_volume = null)
368     {
369         var values = new Dictionary<string, string>
370         {
371             { "postType", "Cartridge" },
372             { "parent_id", parent_id },
373             { "cartridge_model", cartridge_model },
374             { "volume", volume },
375             { "max_volume", max_volume }
376         };
377
378         var content = new FormUrlEncodedContent(values);
379
380         var response = await client.PostAsync("http://10.0.0.125/",
381             content);
382
383         var responseString = await response.Content.ReadAsStringAsync();
384     }
385 }
386
387 #endregion
```